

PARTS LIST

for

MAYTAG[®]

**COMMERCIAL
GAS DRYER**


MODEL NO.(S)

MLG24PDAXW0

LOWER CABINET AND FRONT PANEL PARTS

For Model: MLG24PDAXW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


LOWER CABINET AND FRONT PANEL PARTS

For Model: MLG24PDAXW0
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts (Located Behind Toe Panel)	23	3392915	Gasket, Window	54	718032	Screw
	W10135153	Installation Instructions	24	3394331	Plate Cover (Bottom Exhaust)	55	3390647	Screw
	W10135168	Tech Sheet	25	8564011	Bracket, Switch	56	W10169687	Harness (Lower)
	W10135163	Repair Parts List	26	3389249	Nut, "U"	57	3390735	Seal, Door
2	3391915	Screw	27	W10139766	Motor Assembly (60 Hz.)	58	3392538	Catch, Door Assembly
3	3390663	Screw	28	W10167613	Wire, Belt Switch (To Protector)	59	W10155571	Switch Assembly
4	3391846	Clip, Front Panel	29	3394341	Pulley 60 Hz	60	3392906	Handle, Door
5	8564010	Switch, Broken Belt	30	W10131172	Belt, Drive	61	697215	Panel, Toe (Includes Illus. 34)
6	697773	Screw	31	3390902	Clip, Door Hinge	62	3387561	Clamp-Pipe
7	8310656	Cabinet, Lower	32	W10135695	Bracket, Motor	63	W10135231	Burner Assembly 60 Hz. (Refer To Pages 10 & 11 For Breakdown)
8	3392100	Foot, Dryer Plastic	33	3392186	Washer	64	697441	Valve, Gas (Complete) 60 Hz
9	660658	Clamp, Motor	34	693152	Bumper	65	3387057	Screw
10	3387374	Spring, Idler	35	279731	4"-90 Elbow	66	98997	Clip
11	3389420	Retainer, Idler	36	697750	Plug-Multivent	67	3393657	Belt, Restrain
12	693995	Screw	37	488729	Screw	68	3405160	Belt, Poly V
13	3388672	Pulley Assembly	38	8283298	Jumper, Door Switch	69	W10212660	Sound Pad, Motor
14	3400077	Screw	39	W10141380	Bracket, Idler	Optional Parts Not Included		
15	3392918	Window (Not Shown Part 3396122, Window Pack. Includes Illus. 15 & 23)	40	686590	Ignitor	Dryer Exhaust Kit (For Side & Bottom Venting)		
16	8539892	Wire Motor (To Belt Switch)	41	3406109	Door Switch Assembly	70	279818	White
17	8529757	Bracket, Burner	42	W10002600	Screw			
18	233520	Washer, Thurst	43	3393909	Screw			
19	297092	Clip	44	3387242	Seal, Front Panel			
20	690997	Tri-Ring	45	342055	Screw			
21	3389247	Hinge And Pin	46	3388229	Retainer			
22	3392914	Frame, Window	47	3392905	Door, Rear			
			48	694091	Screw			
			49	3392880	Door, Front			
			50	343641	Screw			
			51	3393081	Upper Front Panel			
			52	696144	Strike, Door			
			53	3393933	Fastener			

CONTROL PANEL AND SEPARATOR PARTS

For Model: MLG24PDAXW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CONTROL PANEL AND SEPARATOR PARTS

For Model: MLG24PDAXW0
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10167621	Harness, Collar	17	W10159907	Mounting Strap Assembly	31	W10165297	Snap Bushing
2	W10139762	Hex Nut, 3/4-27	18	W10133264	Lock Assembly	32	W10131838	Switch, Vault & Service Door
3	3391018	Tie, Cable	19	694415	Strain Relief	33	8540229	RFI-Filter
4	697776	Screw	20	3400408	Screw	34	8533971	Screw
5	W10140652	Screw	21	W10160652	Bracket-Switch	35	W10188051	Jumper, Line Filter
6	W10133285	Transformer 120Vac To 22.5Vac	22	W10137319	Bolt, 10-32 x 6.06	36	W10133266	Locking Cam
7	8533971	Screw	23	W10159849	Collar	37	W10133514	Standoff, Circuit Board
8	W10177242	Hex-Nut 9/32 - 28	24	694018	Cord, Power	38	W10080190	Nut, 3/8-16
9	W10139046	Nut, 6-32	25	W10133258	Vault-Body Assembly	39	3400000	Screw
10	W10131119	Screw	26	W10133277	Membrane Switch Assembly	40	3396795	Cover, Terminal Block
11	W10163677	Plate, Control Mounting	27	W10130700	Control Board	41	W10140858	Key, Access Door
12	W10131113	Push Button	28	3390443	Retainer, Terminal	42	W10169579	Kit-Coin Box Security
13	W10135185	Facia Console	29	W10130178	Coin-Optic Sensor Assembly	43	W10133248	Coin Box
14	W10133245	Coin Drop Assembly	30	W10142655	Screw			
15	W10133268	Cover, Display						
16	W10133280	Switch, Service Access						

UPPER CABINET AND FRONT PANEL PARTS

For Model: MLG24PDAXW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


UPPER CABINET AND FRONT PANEL PARTS

For Model: MLG24PDAXW0
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3390663	Screw	28	W10167613	Wire, Belt Switch (To Protector)	58	3392538	Catch, Door Assembly
2	3391915	Screw	29	3394341	Pulley (60 Hz.)	59	3387057	Screw
3	8539892	Wire Motor (To Belt Switch)	30	W10131172	Belt, Drive	60	3392906	Handle, Door
4	3400077	Screw	31	3390902	Clip, Door Hinge	61	697215	Panel, Toe (Includes Illus. 33)
5	W10155571	Switch Assembly	32	W10135695	Bracket, Motor	62	3389351	Top (Upper)
6	697773	Screw	33	693152	Bumper	63	3391018	Tie, Cable
7	3978859	Cabinet (Upper)	34	279731	4"-90° Elbow	64	63823	Cotter Pin
8	689172	Foot, Dryer Plastic	35	697750	Plug-Multivent	65	W10135231	Burner Assembly 60 Hz. (Refer To Pages 10 & 11 For Breakdown)
9	660658	Clamp, Motor	36	3392186	Washer	66	697441	Valve, Gas (Complete) 60 Hz.
10	3387374	Spring, Idler	37	488729	Screw	67	3387561	Clamp, Pipe
11	3389420	Retainer, Idler	38	8283298	Jumper, Door Switch	68	3393909	Screw
12	3392915	Gasket, Window	39	W10141380	Bracket, Idler	69	686590	Ignitor
13	3388672	Pulley Assembly	40	343641	Screw	70	98997	Clip
14	693995	Screw	41	3406109	Door Switch Assembly	71	3391846	Clip, Front Panel
15	3392918	Window (Not Shown Part 3396122, Window Pack. Includes Illus. 12 & 15)	42	W10002600	Screw	72	3393657	Belt, Restrain
16	8564010	Switch, Broken Belt	43	3389233	Bushing	73	3405160	Belt, Poly V
17	8529757	Bracket, Burner	44	3387242	Seal, Front Panel	74	W10212660	Sound Pad, Motor
18	233520	Washer, Thrust	45	342055	Screw	Optional Parts Not Included		
19	297092	Clip	46	3388229	Retainer	Dryer Exhaust Kit (For Side & Bottom Venting)		
20	690997	Tri-Ring	47	3392905	Door, Rear	75	279818	White
21	3389247	Hinge And Pin	48	694091	Screw			
22	3392914	Frame, Window	49	3392880	Door, Front			
23	3979115	Bracket, Angle	50	718032	Screw			
24	3394331	Plate, Cover (Bottom Exhaust)	51	3393081	Upper Front Panel			
25	8564011	Bracket, Switch	52	696144	Stike, Door			
26	3389249	Nut, "U"	53	3400523	Screw, Security (Includes Illus. 64)			
27	W10139766	Motor Assembly 60 Hz.	54	3393933	Fastener			
			55	3390647	Screw			
			56	W10169686	Harness (Upper)			
			57	3390735	Seal, Door			

UPPER AND LOWER BULKHEAD PARTS

For Model: MLG24PDAXW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER AND LOWER BULKHEAD PARTS


For Model: MLG24PDAXW0
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	16	W10001120	Nut, 3/8-16 (L.H.)	30	W10049370	Lint Screen
2	8066086	Drum Hole Plug	17	8520836	Bulkhead, Rear	31	487909	Screw
3	8533971	Screw	18	3387459	Washer, Support	32	W10168564	Wheel, Blower
4	90767	Screw	19	8575325	Shaft, L.H. Thread	33	8563758	Door, Lint Screen
5	3394346	Air Duct Assembly	20	690997	Ring, Tri	34	W10131836	Thermostat, 140°F Cycling
6	697813	Seal, Outlet Housing	21	8536973	Roller, Support	35	3387230	Screw
7	697814	Seal, Drum Front	22	3391912	Thermostat High Limit	36	W10135254	Housing, Blower
8	3934666	Nut, 3/8 x 16 (R.H.)	23	8563755	Housing, Outlet	37	8066168	Lint Duct Assembly
9	8066224	Exhaust Pipe	24	3401707	Jumper-TCO High Limit	38	8573824	Funnel, Burner
10	8572105	Clip, Exhaust	25	8318215	Drum Complete	39	338906	Sensor, Radiant
11	3357011	Screw	26	W10109200	Screw	40	W10133284	Thermostat 155° Electronic
12	8066208	Clip-Spring	27	W10166807	Seal, Drum	41	697693	Baffle, Drum
13	3390647	Screw	28	3394986	Spring, Lint Screen	42	697557	Bulkhead, Front
14	3402841	Lens, Drum Light	29	8573713	Thermal-Cutoff (Includes Item. 22)	43	8563756	Grille, Outlet
15	8578825	Bracket, Drum Light				44	3392519	Thermal Fuse
						45	697770	Seal, Cover Plate

W10135231 BURNER ASSEMBLY

For Model: MLG24PDAXW0
(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10135231 BURNER ASSEMBLY

For Model: MLG24PDAXW0
(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	W10135231	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8–32 x 5/8)
6	343641	Screw, 10–16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 10–16 x 1/2
9		Orifice, Burner
	234870	Type 1
	234868	Type 2
10	W10141728	Valve, Gas 60 Hz. (Complete)
11	694421	Screw, 8–32 x 1/2
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	W10110395	Pipe, Gas Supply
22	697441	Valve & Union Shut-Off
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

W10436933 Conversion Kit
(Type 1 and 2)
to Type (4) L.P.G.

BA-156B

OPTIONAL PARTS (NOT INCLUDED)

For Model: MLG24PDAXW0
(White)

Illus.	Part	
No.	No.	DESCRIPTION

ACCESSORY PARTS

4392067	Kit, Dryer Repair
285875	Kit, Security
8522199	Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017	White
-------	-------

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350938	Primer, Grey

PAINT, BULK (1 qt.)

799344	White (Uncut)
--------	---------------